

# METSyS NEC 220 LOGGER Firmware Update Instructions

---

## FIRMWARE UPDATE

GMC-I PROSyS may, from time to time, release an updated version of the internal firmware for the METSyS NEC 220 Logger to fix bugs or introduce new features.




**It is recommended that you transfer any logs stored in the instrument to a computer before performing a firmware update.**

If you have an update file and wish to install it on the logger, copy the required update file, **update.bin** to a USB memory stick (it doesn't matter if the memory stick also contains other files and directories).

Insert the memory stick into the bottom of the logger, connect an external AC power source, and select **Firmware Update** on the front panel.

The logger will show the current version of firmware installed as well as the firmware version found on the memory stick as shown in the example of Figure 22.



**Figure 22: Firmware Update Confirmation**

Normally, you would want to replace the firmware with a newer version (higher version number). To replace the internal firmware with the version shown on the meter screen, press the **Up Arrow (Y)**. To cancel, press the **Down Arrow (N)**.

Once the update is confirmed, the progress of the update will be displayed on the screen. After a short while, the logger will restart with the new version of firmware installed.

Remove the memory stick from the meter.

This completes the firmware update.